

Manual LoRaWAN GPS Tracker V2

GPS / GLONASS LoRaWAN Tracker



New version available

This is the manual for a version of our GPS-Tracker, which is no longer manufactured. This hardware revision uses has an addon strip screwed on the basis board, labeled *GPS Addon V2.x* (compare the photograph below). Our current hardware revision is labeled *Lobaro LoRaWAN GPS 3* and does not have an addon strip (compare the photograph in the current revision's manual). Please be sure you are using the manual for the correct hardware revision. Do not install firmware of version 7 or higher on the old hardware revision, as it will not work!

Please refer to [GPS-Tracker Hardware Revisions](#) to find out which hardware you have.


Variant without Power Addon

Order number: 8000014



Variant with Power Addon

Order number: 8000082



- [GPS / GLONASS LoRaWAN Tracker](#)
 - [Variant without Power Addon](#)
 - [Variant with Power Addon](#)
- [Overview](#)
- [Operating the GPS Tracker](#)
 - [Batteries](#)
 - [Installation](#)
- [Work Cycle](#)
 - [Initial Phase](#)
 - [LoRaWAN Join Phase](#)
 - [GPS Collection Phase](#)
 - [Data Transfer Phase](#)
 - [Active Sleep Phase](#)
 - [Alive Sleep Phase](#)
- [Configuration](#)
 - [The Lobaro Maintenance Tool](#)
 - [Connecting the USB config adapter](#)
 - [System Parameters](#)
 - [LoRaWAN](#)
 - [GPS configuration parameters](#)
 - [Cron expressions](#)
- [LoRaWAN Data Upload Formats](#)
 - [Lobaro upload format \(since Firmware Version 5\)](#)
 - [Fields, Data Packet](#)
 - [Status flag](#)
 - [myDevices Cayenne format](#)
 - [Legacy upload format \(up to Firmware Version 4\)](#)
 - [Example](#)
- [Technical characteristics](#)
- [Parser](#)
 - [The Things Network](#)
- [PDF Documentation](#)



Hardware Revisions

The picture above shows the tracker in **hardware revision 2** with GPS and additional GLONASS support for best positioning. Hardware revision 1 with GPS only is no longer available.


[Show pictures of different hardware revisions](#)

Overview

The LoRaWAN GPS Tracker (GPS-LoRaWAN) is a battery powered tracking device, that uses the satellite based positioning services GPS and GLONASS to determine its location and transmits the obtained coordinates via LoRaWAN radio technology. Intervals between measurements can be freely configured, in order to adjust the device to individual needs.

An integrated motion sensor detects changes in the device's movement (if it is picked up or transported in a vehicle). This allows the device to switch between an *Active Mode* in which frequent updates are uploaded during phases of movement and an *Alive Mode* that saves battery power by sending only few updates. While not sending updates, the device enters a sleep mode that only uses 30 μ A.

Please read the manual carefully before operating the device. A safe operation of the device is only possible if you follow the guides provided in this manual. Using the device differently than intended by Lobaro may cause damage to people, the environment, or the device.



Operating the GPS Tracker

Once batteries are inserted into the device, it will start working. The Tracker will most likely need to be adjusted to your personal LoRaWAN configuration (see chapter "Configuration").

Batteries

The LoRaWAN GPS Tracker default power supply consists of two series connected off-the-shelf 1.5V 'AA' sized batteries. Be sure to get the polarity right, see the '+'-Symbol on the board. In general only AA cells of the types Alkali-Manganese (1.5V, LR6) and Lithium-Iron- Sulphide (1.5V, FR6) are allowed to be inserted in the device. Lobaro recommends the use of FR6 batteries like the Energizer Ultimate Lithium over LR6 types because of the higher capacity and better discharge properties.



Warning

Other Batteries or accumulators with a nominal voltage of more than 1.5V must not be inserted into the device under any circumstances. In particular, lithium based cells with a nominal voltage of 3.6V or 3.7V must not be used on the AA battery slots!

On request we can supply custom product variants with special housings powered by even bigger batteries. For example a 3.6V C sized mono cell typically has a capacity of 9Ah with leads to a 3x increased battery life compared to the standard AA-cells. With D sized cells of typically 19Ah capacity this value can be doubled once again (6x). Also available on request are options with permanent external power supply (230V, 9-24V, 5V USB).

Installation


The device can be fixed on a flat surface using the lateral mounting holes of the case, see [Hardware Variations / Accessories](#) for a detailed description of all housing dimensions. Alternatively we offer as accessory a mounting clip for a standard 35mm DIN rail. The device can then easily snapped on a such rails. It can therefore be added to a variety of racks alongside other devices.



Under any circumstances the device must not be mounted higher than 2 meters above ground to avoid any risks in case of falling down!

For optimal RF performance (e.g. LoRa range) any metal obstacles near the internal antenna should be avoided. In this case 'near' is defined as keep-out distance of about 3-5 centimeters around the antenna. The internal helix antenna can be identified by the winding pcb traces near the white printed encircled 'connectivity' symbol. In any case a device mounting directly on top of a metal surface is not advisable since it will degrade the possible RF range. Stone walls, wood or plastic standoffs are perfectly ok. In case of challenging installation locations (e.g. in basements) or unavoidable long distances to the next LoRaWAN gateway, Lobarö offers on request custom product variant equipped with a 'SMA' connector to support a external antenna connection.

Work Cycle



The GPS Tracker has a work cycle that adapts to detected motion of the device.

Initial Phase

This is the phase that is executed after the device is started or restarted. The LED flashes once and the configuration is evaluated. If successful, the LoRaWAN Join phase is executed next.

LoRaWAN Join Phase

If the Device is configured to use over the air activation (OTAA), the OTAA Join is performed at this point. The device will repeatedly try to join its LoRaWAN network until the process is successful. It then enters the Data Collection Phase. If the Device is configured to use ABP instead of OTAA, this phase is left immediately and the Data Collection Phase is entered.

GPS Collection Phase

During the GPS Collection Phase the device will try to determine its coordinates (latitude, longitude, and height) using GPS. You can identify this phase by the onboard LED flashing on and off in one second intervals. Once the position has been determined successfully (or the attempt timed out and failed, because of bad GPS reception), the device enters the Data Transfer Phase.

Data Transfer Phase

During the Data Transfer Phase the Tracker uploads the GPS coordinates to the LoRaWAN network. The message contains the information if the measurement was successful. Some status information about the device are included as well. For a detailed description of the data sent refer to "LoRaWAN Data Upload Formats". After data transfer, the GPS Tracker enters a sleep state to save power. Depending on how much time passed since the last physical movement of the device (determined by the internal motion sensor), the Tracker enters different sleep phases. If the time since the last detected motion is less than a timeout value (configurable, standard value is 65 minutes), the device remains in `Active mode` enters only a short sleep phase (`Active Sleep`). If no motion was detected for a time longer than the timeout, the device enters the `Alive Sleep` Phase, which typically has a much longer sleeping time, but in which the device will also be activated through movement.

Active Sleep Phase


Even in Active Mode, the device spends most of its time in a deep sleep state to conserve energy. The frequency with which the Tracker wakes up in Active Mode can be configured using a Cron expression (see "GPS configuration parameters"). Typical values for active sleep time are 5 or 15 minutes. When in Active Sleep Phase, the device will not be triggered to gather more GPS positions through motion, but movement of the device will still be registered to keep the Tracker in Active Mode.

Alive Sleep Phase

When no movement has been detected for a long amount of time (configurable), the device stops sending updates, since there is not much point in sending frequent position information when the device does not change its position. In Alive Mode, only very few updates are sent to keep the network informed about the device's health. Typically one message is sent per day in this mode (frequency can be configured with a cron expression, see "GPS configuration parameters"). When physical movement is detected by the internal motion sensor during this phase, the GPS Tracker immediately wakes up and switches to Active Mode.

Configuration

The Lobar Maintenance Tool



The initial device configuration can be done very comfortably from your PC via the serial configuration interface. Beside the needed Lobar USB to UART adapter the **Lobar Maintenance Tool** needs to be installed. This tool is freely available for various operating systems including Windows, Linux, Mac and Linux-ARM (e.g. Raspberry-PI) on and works with all Lobar sensors.

Technically this software opens a webserver on port 8585 that runs in a background console window. The actual user interface can be accessed normally using a standard web browser at address <http://localhost:8585>. Normally your default browser should be opened with this URL automatically after tool startup. Even remote configuration and logobservation over the Internet is possible, e.g. having a Raspberry PI via USB connected to the Lobar device and accessing the maintenance tool from a remote machines browser over the Internet.

Additionally to the device setup the tool can also be used for firmware updates ('Firmware Tab'), watching real-time device diagnostic output ('Logs Tab') and initiating device restarts.




Please note that the device might be restarted each time the configuration gets plugged /unplugged!

Connecting the USB config adapter

For configuration and Firmware updates we provide a special serial-USB adapter that can be connected as shown in the picture underneath. The corresponding connector on the PCB is marked with the word 'Config'.

The USB-adapter will add a virtual serial 'COM' Port to your system. Your operating system needs the **CP 210x USB to UART bridge** driver installed. A download link is provided next to the 'Connect' button when you start the Maintenance Tool. While the config adapter is connected, the device will be powered from the USB port with a regulated voltage of 3.3V. It is not necessary - although it would be no problem - having batteries inserted or a different supply connected while using the config adapter. All configuration parameters will be kept non-volatile regardless of the power supply.



Hardware Revisions

The picture above shows the tracker in **hardware revision 1** with GPS only support. Hardware revision 1 with GPS only is no longer available.

System Parameters

After being successfully connected to the hardware using the Lobaro Maintenance Tool you can press 'Reload Config' in the 'Configuration' tab to read the current configuration from the device. For every parameter a default value is stored non volatile inside the hardware to which you can revert using the 'Restore default' button in case anything got miss configured. All LoRaWAN & other firmware parameters are explained in the following.

LoRaWAN

The connection to the LoRaWAN network is defined by multiple configuration parameters. This need to be set according to your LoRaWAN network and the way your device is supposed to be attached to it, or the device will not be able to send any data.

For a detailed introduction into how this values need to be configured, please refer to the chapter [LoRaWAN configuration](#) in our LoRaWAN background article.

Name	Description	Type	Values
OTAA	Activation: OTAA or ABP	bool	true= use OTAA, false= use ABP
DevEUI	DevEUI used to identify the Device	byte[8]	e.g. 0123456789abcdef
JoinEUI	Used for OTAA (called AppEUI in v1.0)	byte[8]	e.g. 0123456789abcdef
AppKey	Key used for OTAA (v1.0 and v1.1)	byte[16]	
NwkKey	Key used for OTAA (v1.1 only)	byte[16]	
SF	Initial / maximum Spreading Factor	int	7 - 12
ADR	Use Adaptive Data Rate	bool	true= use ADR, false= don't
OpMode	Operation Mode	string	A= Class A, C= Class C
TimeSync	Days after which to sync time	int	days, 0=don't sync time
RndDelay	Random delay before sending	int	max seconds
RemoteConf	Not supported by this firmware	bool	false=deactivate
LostReboot	Days without downlink before reboot	int	days, 0=don't reboot

GPS configuration parameters

The behaviour of the GPS Tracker and how it switches between its two operation modes ('Active' and 'Alive') can be adjusted to your needs. The table explains the configuration parameters used for this.

Name	Type	Description	default value
ActiveCron	string	Cron expression defining how often the device will take a measurement and send its position over LoRaWAN while the Tracker is in Active Mode. This expression should trigger much more frequent than the one for Alive Mode. The standard is 0 0/15 * * *, which will trigger every 15 minutes. See chapter "Cron expressions" for an introduction to cron expressions.	0 0/15 * * *
AliveCron	string	Cron expression defining how often the device will wake up when in Alive Mode. This should be less frequent than in Active Mode. The standard is 0 0 0 /12 * * *, which translates to twice each day. See chapter "Cron expressions" for an introduction to cron expressions.	0 0 0/12 * * *
gpsTO	int	Time in seconds to wait for GPS to get a fix before timing out.	180 seconds
actTO	int	Time in minutes without movement after which the Tracker switches to Alive Mode.	65 minutes
memsTh	int	Threshold for the internal motion detector to register movement. Values range from 2 to 255. A higher value makes the device less sensitive. 2 Environment (wind or steps) may trigger. 5 Standard, picking up the device will activate it. 20 Carefully picking it up will not trigger the device. 50 When carried, running will trigger, walking won't. 100+ Shaking will activate, dropping the device might not.	5
Cayenne LPP	bool	Use alternative Cayenne LPP upload format. Standard: false, e.g. use LobarO Format. See chapter "myDevices Cayenne format" for an introduction to this format.	false
maxHDOP	int	Maximum acceptable Horizontal Dilution Of Precision, between 1 and 50, smaller is better	2
maxData AfterFix	int	If the HDOP target cannot be matched this value determines after how many datapackets with fix the position will be accepted	20

Cron expressions

Cron expressions are used to define specific points in time and regular repetitions of them. The schedule for data collecting phases is defined using the [CRON](#) format which is very powerful format to define repeatedly occurring events.



Standard LobarO devices typically do not need to know the real time for proper operation. All times are relative to the initial time when batteries are inserted.

If needed by the target application LobarO can deliver on request special hardware support for keeping data acquisition intervals based on a real time clock which stays in sync with the real time. Please contact LobarO directly if you need such a custom product variant.

A cron expression consists of 6 values separated by spaces:

- Seconds (0-59)
- Minutes (0-59)
- Hours (0-23)
- Days (1-31)
- Month (1-12)
- Day of Week (SUN-SAT b= [0,6])

Examples of CRON definitions:

0 5 ****	hourly at minute 5, second 0 (at 00:05:00, 01:05:00, ...)
0 1/10 * * * *	every 10 minutes from minute 1, second 0 (minutes 1, 11, 21, ...)
0 0 6 * * *	daily at 6:00:00
0 0 13 1,15 * *	1 st and 15 th day of every month at 13:00:00
0 0 9 1-5 * *	every month daily from day 1 till 5 at 9:00:00

LoRaWAN Data Upload Formats

After reading GPS coordinates (either successfully or unsuccessfully), the Tracker uploads the data using LoRaWAN. As LoRaWAN can only transmit very short messages, the message formats contain only data bytes, no keys or data types are included. The meaning of a byte is determined by its position within a message. The tracker supports two different upload formats as described in the following:

Lobaro upload format (since Firmware Version 5)

Only a single message format is used by the GPS Tracker, it has a fixed length of 17 bytes. The table explains the message format used. This format uses the decimal degrees notation for the location, e.g. 53.4724° north and 9.9334° east. Positive (+) values indicate north longitudes and east latitudes, negative (-) values indicate south longitudes and west latitudes. Both location values are transmitted as signed integers in *big endian* format and get multiplied by 100.000. So after receiving the location data must be divided by this factor. Multi byte integers are transmitted as big endian. Values that would require decimal places are transmitted in smaller units, e.g. 1/100000 degree (as described before), to handle only with integers.

Fields, Data Packet

name	bytes	type	description	example / range
temp	0-1	int16	Temperature inside the device in 1/10°C	246 = 24.6 °C
v_bat	2-3	uint16	Current battery voltage in mV	3547 = 3.547 V
latitude deg	4-7	int32	int32 degrees of the latitude x 100 000	-9 000 000 to 9 000 000
longitude deg	8-11	int32	degrees of the longitude x 100 000	-18 000 000 to 18 000 000
altitude	12-14	int24	Altitude of the device in centimeters	-8 388 607 to 8 388 606
flags	15	uint8	Status flag, refer to table below	00bin = invalid, alive 01bin = valid, alive 10bin = invalid, active 11bin = valid, active
sat	16	uint8	GPS satellites found / in view	7

Status flag

bit	function	not set	set
1	Validity of last measurement	invalid	valid
2	Current operation mode	alive	active
3-8	reserved for future use		

If during some configurable period of time (see "gpsTO" parameter in table "GPS configuration parameters") no GPS location can be found the last known valid GPS location will be transmitted but with the valid flag set to false. We provide a [JavaScript reference implementation](#) of a decoder for the data packages, which can be used directly for decoding in [The Things Network](#).

myDevices Cayenne format

As an alternative for the Lobaro data format the tracker can be configured to send Cayenne LPP compatible LoRaWAN uploads. [myDevices Cayenne](#) allows you to quickly visualize the via LoRaWAN transmitted data of the Lobaro GPS-tracker. You can use Cayenne as a tool to visualize real-time and historical data, sent over The Things Network and various other LoRaWAN providers. To use the alternative upload format configuration parameter "CayenneLPP" must be set to "true" as described in section "GPS configuration parameters". The advantages of using the cayenne format is a quick device evaluation without programming some custom backend and/or front software. Disadvantages are bigger LoRaWAN message sizes due to the additional schema meta information overhead the format needs.

The Lobaro GPS Trackers maps its data to cayenne channels as follows:

description	cayenne channel	cayenne type
Internal Temperature	0	Temperature

Battery Voltage	1	AnalogOutput
GPS data	2	GPS
satellites found	3	Digital Output

Legacy upload format (up to Firmware Version 4)

This format is not supported any more since firmware version V5.0.0! Please consider updating your device firmware using the Lobar maintenance tool. Only a single message format is used by the GPS Tracker, it has a fixed length of 15 bytes. This format uses the degrees with decimal minutes notation for the location. Multi byte integers are transmitted as big endian. Values that would require decimal places are transmitted in smaller units (e.g. mV instead of V). The table underneath explains the message format used.

name	type	description	example/range
flags	uint8	Status flags, for internal use	0
temp	int16	Temperature inside the device in 1/10°C	246 24.6 °C
v_bat	uint16	Current battery voltage in mV	3547 3:547 V
latitude deg	int8	Whole degrees of the latitude	-90 to 90

Example




As an illustration, if the received data would consist of the 15 bytes (hexencoded):

00 01 18 0D 69 35 1C 0F 71 09 38 02 4B 01 06

type	example	description
flag	00	for internal use, ignore
temp	01 18	0118 hex = 0280dec 280 d°C = 28.0 °C
v_bat	0D 69	0D89 hex = 3465dec 3465mV = 3.465V
latitude	35 1C 0F 71	35hex = 53dec 53° 1C hex = 28dec 28' 0F71 hex = 3953dec 0.3953' 351C0F71 53°28.3952' = 53.473255° = 53°28'23.718" North
longitude	09 38 02 4B	09 hex = 09dec 09° 38 hex = 56dec 56' 024B hex = 0587dec 0.0587' 0938024B 9°56.0587' = 9.934 312° = 9°56'3.522" East
valid	01	01hex valid measurement, could receive GPS signal
sat	06	06hex = 06dec Signal of 6 satellites received for measurement

Technical characteristics

Product	
Type name	GPS-LoRaWAN
Description	LoRaWAN GPS Tracker

RF transceiver	
Chipset	Semtech SX1272
Frequency Range	863 to 870 MHz
TX Power	14 dBm
Typically RF range	2km
Ideal RF range	10km (free line of sight)
LoRa communication	
LoRaWAN Protocol	LoRaWAN 1.0.1, Class A, EU868
Activation method	Over-the-air activation (OTAA) Activation by personalization (ABP)
Encryption	AES128
Power	
Power supply	2xAA sized battery, 1.5 V, LR6/FR6
Supply voltage	UNom = 3.0V, UMin = 2.2V, UMax = 3.7V
Capacity	30000 LoRaWAN messages @SF11
Current consumption @3V	
Normal	3 mA
Wireless M-BUS RX	14 mA
LoRa RX	14 mA
LoRa TX	80 mA
Sleep with GPS standby and MEMS running	20 µA
Mechanical dimensions	
Size	114.3 mm x 59.3 mm x 26.8 mm
Housing Material	ABS plastic
Environmental Requirements	
Operating temperature range	-20°C to +55°C
Max. Installation height	2m
Conformity	
	

Parser

The Things Network

For Version 4.x, 5.x and 6.x

```
function signed(val, bits) {
  if ((val & 1 << (bits-1)) > 0) { // value is negative (16bit 2's
    complement)
    var mask = Math.pow(2, bits) - 1;
    val = (~val & mask) + 1; // invert all bits & add 1 => now
    positive value
    val = val * -1;
  }
}
```

```

    }
    return val;
}

function int16_BE(bytes, idx) {
    bytes = bytes.slice(idx || 0);
    return signed(bytes[0] << 8 | bytes[1] << 0, 16);
}

function int24_BE(bytes, idx) {
    bytes = bytes.slice(idx || 0);
    return signed(bytes[0] << 16 | bytes[1] << 8 | bytes[2] << 0, 24);
}

function int32_BE(bytes, idx) {
    bytes = bytes.slice(idx || 0);
    return signed(bytes[0] << 24 | bytes[1] << 16 | bytes[2] << 8 | bytes
[3] << 0, 32);
}

function DecoderPort2(bytes) {
    // Format for firmware 5.0.x
    // Decode an uplink message from a buffer
    // (array) of bytes to an object of fields.

    var Temp = int16_BE(bytes, 0) / 10;
    var VBat = int16_BE(bytes, 2) / 1000;
    var Lat = int32_BE(bytes, 4) / 100000;
    var Lon = int32_BE(bytes, 8) / 100000;
    var Alt = int24_BE(bytes, 12) / 100;
    var Valid = bytes[15] & 0x01;
    var Active = bytes[15] & 0x02;
    var SatCnt = bytes[16];

    return {
        Temp: Temp || 0,
        VBat: VBat || 0,
        Lat: Lat || 0,
        Lon: Lon || 0,
        Alt: Alt || 0,
        Valid: Valid,
        Active: Active,
        SatCnt: SatCnt
    };
}

function DecoderPort1(bytes) {
    // legacy format, firmware 4.x
    // Decode an uplink message from a buffer
    // (array) of bytes to an object of fields.

    var button_number = bytes[0];
    var Temp10tel = (bytes[1] << 8) | (bytes[2] << 0);
    var VBat1000tel = (bytes[3] << 8) | (bytes[4] << 0);
    var lat_deg = bytes[5];
    var lat_min = bytes[6];
    var lat_10000min = (bytes[7] << 8) | (bytes[8] << 0);
    var long_deg = bytes[9];
    var long_min = bytes[10];
    var long_10000min = (bytes[11] << 8) | (bytes[12] << 0);
    var gpsValid = (bytes[13] !== 0); // Missing byte = true

    return {
        button_number: button_number || 0,
        Temp10tel: Temp10tel || 0,
        VBat1000tel: VBat1000tel || 0,
        lat_deg: lat_deg || 0,
        lat_min: lat_min || 0,
        lat_10000min: lat_10000min || 0,
        long_deg: long_deg || 0,
        long_min: long_min || 0,

```

```

        long_10000min: long_10000min || 0,
        gps_valid: gpsValid || false
    };
}

function Decoder(bytes, port) {
    switch (port) {
        case 1:
            return DecoderPort1(bytes);
        case 2:
            return DecoderPort2(bytes);
        default:
            return {"error": "Unsupported port", "port": port};
    }
}

// Wrapper for Lobar Platform
function Parse(input) {
    // Decode an incoming message to an object of fields.
    var b = bytes(atob(input.data));
    var decoded = Decoder(b, input.fPort);

    return decoded;
}

// Wrapper for Loraserver / ChirpStack
function Decode(fPort, bytes) {
    return Decoder(bytes, fPort);
}

// Wrapper for Digimondo niota.io (uncomment only when used in niota)
/*
module.exports = function (payload, meta) {
    const port = meta.lora.fport;
    const buf = Buffer.from(payload, 'hex');

    return Decoder(buf, port);
}*/

```

PDF Documentation

- [Product Dimensions \(pdf\)](#)
- [User Manual \(en\)](#)
- [CE Declaration of Conformity](#)