



GPS Tracker V3 (LoRaWAN)

GPS-LoRaWAN V3



Order number: 8000116



Order number: 8000135

- Key Features
- Overview
 - Operating the GPS Tracker
 - Batteries
 - Installation
 - Life Cycle
 - Initial Phase
 - LoRaWAN Join Phase
 - GPS Collection Phase
 - Data Transfer Phase
 - Active Sleep Phase
 - Passive Sleep Phase
 - Configuration
 - The Lobaro
 - Maintenance Tool
 - Connecting the USB config adapter
 - System Parameters
 - LoRaWAN
 - GPS configuration parameters
 - Cron expressions
 - LED patterns
 - LoRaWAN Data Upload Formats
 - Numerical values
 - Status Message
 - Firmware and Version
 - Status Code
 - Reboot reason
 - Final word
 - Voltage
 - Temperature
 - Flags
 - Data Message
 - Temperature and Voltage
 - Position and Timestamp
 - Position Quality
 - Flags
 - Example Data Message
- Parser
- TTN-Mapper
 - Configuration
 - Parser
 - Integration
- Technical characteristics
- Disposal
- PDF Documentation

Different Hardware Revision

This manual is for the GPS-Tracker in hardware revision 3 running firmware starting with version 7.0.0. It is not compatible to older hardware revisions. If you have an older revision of the device or are unsure which revision you have, please refer to the [Hardware Revisions Overview](#), which also links to the manuals for each revision.

Key Features

- ✓ LoRaWAN 1.0.x and 1.1 network servers supported
- ✓ TTN-Mapper compatible
- ✓ Time synchronisation via GPS
- ✓ Simultaneous GPS and BeiDou support for better satellite coverage
- ✓ Configuration via USB or remotely via LoRaWAN downlink
- ✓ Visual Feedback through on-board LED
- ✓ Power conserving when stationary (Passive Mode)
- ✓ Integrated motion detector and temperature sensor
- ✓ Optional: complete Lobaro IoT Platform integration

Overview

The LoRaWAN GPS Tracker (GPS-LoRaWAN V3) is a battery powered tracking device, that uses the satellite based positioning services [GPS](#) and [BeiDou](#) to determine its location and transmits the obtained coordinates via LoRaWAN radio technology. Intervals between measurements can be freely configured, in order to adjust the device to individual needs.

An integrated motion sensor detects changes in the device's movement (if it is picked up or transported in a vehicle). This allows the device to switch between an `Active Mode` in which frequent updates are uploaded during phases of movement and an `Passive Mode` that saves battery power by sending only few updates. While not sending updates, the device enters a sleep mode that only uses 25 μA (or $\sim 14 \mu\text{A}$ without motion sensor).



Please read the manual carefully before operating the device. A safe operation of the device is only possible if you follow the guides provided in this manual. Using the device differently than intended by Lobaromy cause damage to people, the environment, or the device.

Quick-start

This is a basic guide to get the GPS-Tracker running using the free LoRaWAN-Network [The Things Network](#) (TTN). TTN supply documentation that helps you in following this steps. Any LoRaWAN-Network can be used. Refer to the rest of the manual for detailed information.

- Create an account on [The Things Network](#)
- Create a new application for the Lobaromy GPS Tracker V3
- Copy our [Reference Parser](#) to your application
- Create a new Device in your new application in TTN
- Adjust the device parameters `DevEUI`, `AppEUI/JoinEUI`, and `AppKey`. Either change the values in the TTN-Device entry or change the configuration of the GPS-Tracker using the Lobaromy Config Adapter
- Make sure you have coverage by a TTN-Gateway and GPS (outside)
- Insert batteries into the tracker
- Check for data in TTN

Operating the GPS Tracker

Once batteries are inserted into the device, it will start working. The Tracker will most likely need to be adjusted to your personal LoRaWAN configuration (see chapter "Configuration").

Batteries

Please see our page on [Battery Disposal](#).

The LoRaWAN GPS Tracker default power supply consists of two series connected off-the-shelf 1.5V 'AA' sized batteries. Be sure to get the polarity right, see the '+'-Symbol on the board. In general only AA cells of the types Alkali-Manganese (1.5V, LR6) and Lithium-Iron- Sulphide (1.5V, FR6) are allowed to be inserted in the device. Lobaromy recommends the use of FR6 batteries like the Energizer Ultimate Lithium over LR6 types because of the higher capacity and better discharge properties.



Other Batteries or accumulators with a nominal voltage of more than 1.5V must not inserted into the device under any circumstances. In particular, lithium based cells with a nominal voltage of 3.6V or 3.7V must not be used on the AA battery slots!

On request we can supply custom product variants with special housings powered by even bigger batteries. For example a 3.6V C sized mono cell typically has a capacity of 9Ah with leads to a 3x increased battery life compared to the standard AA-cells. With D sized cells of typically 19Ah capacity this value can be doubled once again (6x).

Installation


The device can be fixed on a flat surface using the lateral mounting holes of the case, see [Hardware Variations / Accessories](#) for a detailed description of all housing dimensions. Alternatively we offer as accessory a mounting clip for a standard 35mm DIN rail. The device can then easily snapped on a such rails. It can therefore be added to a variety of racks alongside other devices.



Under any circumstances the device must not be mounted higher than 2 meters above ground to avoid any risks in case of falling down!

For optimal RF performance (e.g. LoRa range) any metal obstacles near the internal antenna should be avoided. In this case 'near' is defined as keep-out distance of about 3-5 centimetres around the antenna. The internal helix antenna can be identified by the winding pcb traces on the right side of the board. In any case a device mounting directly on top of a metal surface is not advisable since it will degrade the possible RF range. Stone walls, wood or plastic standoffs are perfectly ok. In case of challenging installation locations (e.g. in basements) or unavoidable long distances to the next LoRaWAN gateway, Lobaromy offers custom product variant equipped with a 'SMA' connector to support a external antenna connection on request.

Work Cycle



The GPS Tracker has a work cycle that adapts to detected motion of the device.

Initial Phase

This is the phase that is executed after the device is started or restarted. The LED flashes once and the configuration is evaluated. If successful, the LoRaWAN Join phase is executed next.

LoRaWAN Join Phase

If the Device is configured to use over the air activation (OTAA), the OTAA Join is performed at this point. The device will repeatedly try to join its LoRaWAN network until the process is successful. It then enters the Data Collection Phase. If the Device is configured to use ABP instead of OTAA, this phase is left immediately and the Data Collection Phase is entered.

GPS Collection Phase

During the GPS Collection Phase the device will try to determine its coordinates (latitude, longitude, and height) using GPS. You can identify this phase by the onboard LED flashing on and off in one second intervals. Once the position has been determined successfully (or the attempt timed out and failed, because of bad GPS reception), the device enters the Data Transfer Phase.

During this phase the Tracker gives visual feedback over its LED. See [LED Patterns](#) for an explanation.

Data Transfer Phase

During the Data Transfer Phase the Tracker uploads the GPS coordinates to the LoRaWAN network. The message contains the information if the measurement was successful. Some status information about the device are included as well. For a detailed description of the data sent refer to "LoRaWAN Data Upload Formats". After data transfer, the GPS Tracker enters a sleep state to save power. Depending on how much time passed since the last physical movement of the device (determined by the internal motion sensor), the Tracker enters different sleep phases. If the time since the last detected motion is less than a timeout value (configurable, standard value is 65 minutes), the device remains in `Active` mode enters only a short sleep phase (`Active Sleep`). If no motion was detected for a time longer than the timeout, the device enters the `Passive Sleep` Phase, which typically has a much longer sleeping time, but in which the device will also be activated through movement.

Active Sleep Phase


Even in Active Mode, the device spends most of its time in a deep sleep state to conserve energy. The frequency with which the Tracker wakes up in Active Mode can be configured using a Cron expression (see "GPS configuration parameters"). Typical values for active sleep time are 5 or 15 minutes. When in Active Sleep Phase, the device will not be triggered to gather more GPS positions through motion, but movement of the device will still be registered to keep the Tracker in Active Mode.

Passive Sleep Phase

When no movement has been detected for a long amount of time (configurable), the device stops sending updates, since there is not much point in sending frequent position information when the device does not change its position. In Passive Mode, only very few updates are sent to keep the network informed about the device's health. Typically one message is sent per day in this mode (frequency can be configured with a cron expression, see "GPS configuration parameters"). When physical movement is detected by the internal motion sensor during this phase, the GPS Tracker immediately wakes up and switches to Active Mode.

Configuration

The Lobar Maintenance Tool



The initial device configuration can be done very comfortably from your PC via the serial configuration interface. Beside the needed Lobarco USB to UART adapter the **Lobarco Maintenance Tool** needs to be installed. This tool is freely available for various operating systems including Windows, Linux, Mac and Linux-ARM (e.g. Raspberry-PI) on and works with all Lobarco sensors.

Technically this software opens a webserver on port 8585 that runs in a background console window. The actual user interface can be accessed normally using a standard web browser at address <http://localhost:8585>. Normally your default browser should be opened with this URL automatically after tool startup. Even remote configuration and logobservation over the Internet is possible, e.g. having a Raspberry PI via USB connected to the Lobarco device and accessing the maintenance tool from a remote machines browser over the Internet.

Additionally to the device setup the tool can also be used for firmware updates ('Firmware Tab'), watching real-time device diagnostic output ('Logs Tab') and initiating device restarts.




Please note that the device might be restarted each time the configuration gets plugged /unplugged!

Connecting the USB config adapter

For configuration and Firmware updates we provide a special serial-USB adapter that can be connected as shown in the picture underneath. The corresponding connector on the PCB is marked with the word 'Config'.

The USB-adapter will add a virtual serial 'COM' Port to your system. Your operating system needs the [CP 210x USB to UART bridge](#) driver installed. A download link is provided next to the 'Connect' button when you start the Maintenance Tool. While the config adapter is connected, the device will be powered from the USB port with a regulated voltage of 3.3V. It is not necessary - although it would be no problem - having batteries inserted or a different supply connected while using the config adapter. All configuration parameters will be kept non-volatile regardless of the power supply.



System Parameters

After being successfully connected to the hardware using the Lobar Maintenance Tool you can press 'Reload Config' in the 'Configuration' tab to read the current configuration from the device. For every parameter a default value is stored non volatile inside the hardware to which you can revert using the 'Restore default' button in case anything got miss configured. All LoRaWAN & other firmware parameters are explained in the following.

LoRaWAN

The connection to the LoRaWAN network is defined by multiple configuration parameters. This need to be set according to your LoRaWAN network and the way your device is supposed to be attached to it, or the device will not be able to send any data.

For a detailed introduction into how this values need to be configured, please refer to the chapter [LoRaWAN configuration](#) in our LoRaWAN background article.

Name	Description	Type	Values
OTAA	Activation: OTAA or ABP	bool	true= use OTAA, false= use ABP
DevEUI	DevEUI used to identify the Device	byte[8]	e.g. 0123456789abcdef
JoinEUI	Used for OTAA (called AppEUI in v1.0)	byte[8]	e.g. 0123456789abcdef
AppKey	Key used for OTAA (v1.0 and v1.1)	byte[16]	
NwkKey	Key used for OTAA (v1.1 only)	byte[16]	
SF	Initial / maximum Spreading Factor	int	7 - 12
RndDelay	Random delay before sending	int	max seconds to wait
RemoteConf	Not supported by this firmware	bool	true=enabled, false=deactivated
LostReboot	Days without downlink before reboot	int	days, 0=don't reboot

GPS configuration parameters

The behaviour of the GPS Tracker and how it switches between its two operation modes ('Active' and 'Passive') can be adjusted to your needs. The table explains the configuration parameters used for this.

Name	Type	Description	default value
statusCron	string	Cron expression defining how often the device will Send a status message.	0 0 0 * * *
activeCron	string	Cron expression defining how often the device will take a measurement and send its position over LoRaWAN while the Tracker is in Active Mode. This expression should trigger much more frequent than the one for Passive Mode. The standard is 0 0/15 * * * *, which will trigger every 15 minutes. See Cron expressions for an introduction to cron expressions.	0 0/15 * * * *
passiveCron	string	Cron expression defining how often the device will wake up when in Passive Mode. This should be less frequent than in Active Mode. The standard is 0 0 0 /12 * * *, which translates to twice each day. See Cron expressions for an introduction to cron expressions.	0 0 0 /12 * * *
gpsTO	int	Time in seconds to wait for GPS to get a fix before timing out.	180 seconds
activeTO	int	Time in minutes without movement after which the Tracker switches to Passive Mode.	65 minutes
timeSyncGps	bool	Update internal clock from GPS signal?	true
memsTh	int	Threshold for the internal motion detector to register movement. Values range from 2 to 255. A higher value makes the device less sensitive. 2 Environment (wind or steps) may trigger. 5 Standard, picking up the device will activate it. 20 Carefully picking it up will not trigger the device. 50 When carried, running will trigger, walking won't. 100+ Shaking will activate, dropping the device might not.	5
maxHDOP	int	Maximum acceptable Horizontal Dilution Of Precision, between 1 and 50, smaller is better	2
maxDataAfterFix	int	If the HDOP target cannot be matched this value determines after how many datapackets with fix the position will be accepted, Min. Value: 3	20

moveDistance	int	(since 7.1.0) travelled distance in metres between two GPS-measurements, that counts as movement event, that triggers active mode	100
--------------	-----	---	-----

Cron expressions

Cron expressions are used to define specific points in time and regular repetitions of them. The schedule for data collecting phases is defined using the **CRON** format which is very powerful format to define repeatedly occurring events.



Internal Device's Clock

Standard Lobar devices typically do not need to know the real time for proper operation. If time synchronisation is disabled (or did not succeed, yet), all times are relative to the initial time when batteries are inserted.

Also be aware that the internal clock runs using **UTC**, so a cron expression triggering at midnight will trigger at one or two 'o clock in the morning in Germany, depending on the status of daylight saving time.

A cron expression consists of 6 values separated by spaces:

- Seconds (0-59)
- Minutes (0-59)
- Hours (0-23)
- Days (1-31)
- Month (1-12)
- Day of Week (SUN-SAT = 0-6)

Examples of CRON definitions:

0 5 * * * *	hourly at minute 5, second 0 (at 00:05:00, 01:05:00, ...)
0 1/10 * * * *	every 10 minutes from minute 1, second 0 (minutes 1, 11, 21, ...)
0 0 6 * * *	daily at 6:00:00
0 0 13 1,15 * *	1 st and 15 th day of every month at 13:00:00
0 0 9 1-5 * *	every month daily from day 1 till 5 at 9:00:00

LED patterns

The GPS-Tracker gives visual feedback about it's operations using a green on-board LED.

Meaning	Pattern	Explanation
Device Start	— single ½ second blink	Device just (re-)booted, testing LED
GPS active	• • • • • ... short blinks every second	GPS module is active and Tracker is trying to get a Position Fix
GPS fix	— — two long blinks	GPS process completed, valid position determined
GPS failed	— • • • • • one long and 5 short blinks	GPS process timed out, no position determined

LoRaWAN Data Upload Formats



Compatibility note

Please be aware, that the payload format changed for the version 7.0.0 of the firmware. It is only partly compatible to older payload formats. Refer to older manuals, for the legacy download format (see the [Hardware Revision Overview](#) page).

The device uploads several different message types each with their own purpose and on their own port.

Port	Size	Message
1	14 bytes	Status Message, containing information about the status of the device.
2	23 bytes	Data Message, containing positional information gained by GNSS (GPS/Beidou).
128-131	varying	Responses to remote configuration commands.

Numerical values

Numerical values are uploaded as integers. If a value needs a higher precision, it is encoded using a smaller unit, for example the measured temperature is transmitted in 10th °C. The value can easily be converted to °C by the parser in your network server. Integers are used signed or unsigned and in various sizes as needed, so unusual sized, like `int24` or `int40` can be found. All multi byte values are encoded in [big endian](#) (Network Byte Order). See our [Reference Parser](#) implementation to see how you can handle those values.

Status Message

After booting and joining the LoRaWAN-Network, the device uploads a Status Message on Port 1 that contains information about the device itself and state. This message is sent regularly, configured by the parameter `statusCron`. The default behaviour is to send the status message once every day. Lobarö recommends this setting to make sure you are always up to date on your devices whereabouts, and to make remote configuration reliable. The message has a fixed length of 14 bytes and is transmitted on port 1. Byte positions are counted starting with 0.

Name	Bytes	Type	Description	Values
Firmware	0-2	char[3]	Firmware identifier	constant: GPS
Version	3-5	uint8[3]	Three numbers indicating firmware version	0x07000a = v7.0.10
Status	6	uint8	Status Code indicating device's condition	0 = OK
Reboot reason	7	uint8	Code indicating reason for last reboot	0x06 = Reset button pressed
Final words	8	uint8	reserved for future use	0
Voltage	9-10	uint16	Battery voltage in mV	0x0c38 = 3128 = 3.128V
Temp	11-12	int16	Internal Temperature in 10 th °C	0x0102 = 258 = 25.8°C
Flags	13	bit[8]	Application state	0b01 = passive mode, position valid

Firmware and Version

Firmware is a constant three byte value containing three ASCII chars, indicating what firmware is running on the device. For this firmware it is always 'GPS'.

Version shows the version of the firmware running on the device, encoded as three independent `uint8` values.

Status Code

Status is a numeric code transmitted as `uint8`, that gives a self diagnostic:

Status Code	Status Name	Meaning
-------------	-------------	---------

0	OK	Normal operation, no problems detected.
101	GPS_ERROR	The devices GPS-Module does not respond.
102	MEMS_ERROR	The motion detector does not respond.
103	GPS_AND_MEMS_ERROR	Neither GPS-Module nor motion detector respond.

Reboot reason

Reboot reason is a numeric code transmitted as `uint8`, that tells why the device did restart when it last booted (which might be a long time ago, the value is repeated in every status message). This value is useful for troubleshooting and error detection.

Reboot Code	Reboot Reason	Explanation
1	LOW_POWER_RESET	Supply voltage broke, batteries might need replacing.
2	WINDOW_WATCHDOG_RESET	
3	INDEPENDENT_WATCHDOG_RESET	
4	SOFTWARE_RESET	Firmware triggered a reboot.
5	POWER_ON_RESET	Power was turned on / Batteries were inserted.
6	EXTERNAL_RESET_PIN_RESET	Reset button pressed / Reset by config adapter.
7	OBL_RESET	

Final word

This value is currently not used and reserved for future usage.

Voltage

Supply voltage fed into the device, either from battery or external power source. Gives an indication on the state of the battery used. The voltage is measured in millivolts (mV) and transmitted as a `uint16`.

Temperature

The device has an internal temperature sensor, that is used to measure the temperature of the device itself. This can give an idea where the device is located (inside/outside) and acts as a diagnostic in case of failure (if the device is exposed to hazardous temperatures). The temperature is measured in 10th of °C and transmitted as an `int16`.

Flags

Internal application state, see same value in [Data Message](#).

Data Message

After reading coordinates from GPS, the device uploads a data message containing the position data. This happens even when the device did not get a fix on its position. If no new position could be determined, the last known valid position is uploaded (together with a timestamp of when that position was valid). This makes it possible to get position data, even if the Tracker does not have GPS coverage and LoRaWAN coverage at the same time.

The data message is 28 bytes long and transmitted on port 2. The message is partly compatible with the data message of older firmware (versions 5 and 6); only new values have been appended at the end. Byte positions are counted starting with 0.

Name	Bytes	Type	Description	Values/Examples
Temperature	0-1	int16	Internal Temperature in 10 th °C	0x0102 = 258 = 25.8 °C

Voltage	2-3	uint16	Battery voltage in mV	0x0c38 = 3128 = 3.128V
Latitude	4-7	int32	Degrees Latitude * 100000	-9000000-9000000
Longitude	8-11	int32	Degrees Longitude * 100000	-18000000-18000000
Altitude	12-14	int24	Altitude in cm	0x0034c6 = 13510 = 135.1m
Flags	15	bit[8]	Application state	0b01 = passive mode, position valid
SatCnt	16	uint8	Number of satellites used for fix	0x06 = 6
HDOP	17	uint8	1/10 * Horizontal Dilution of Precision	0x0f = 15 = HDOP 1.5
Timestamp	18-22	int40	UNIX Timestamp of position data in message (0 for never)	0x005eccd15f = 1590481247 = 2020-05-26T08:20:47 UTC
Movement	23-27	int40	(since 7.1.0) UNIX Timestamp of last movement event (0 for never). Either MEMS or GPS movement	0x005eccd15f = 1590481247 = 2020-05-26T08:20:47 UTC

Temperature and Voltage

Same as in Status Message, useful for checking the health of the device.

Position and Timestamp

The Position data is the main purpose of the Tracker. It is always combined with a timestamp. This timestamp is independent of the internal clock of the Tracker, but taken directly from the GPS data. It is therefore the exact point of time that the position was determined. The time is encoded as a [UNIX-Timestamp](#). A value of 0 (which translates to 1970-01-01T00:00:00) indicates that the Tracker did never get a fix on it's position. So if the timestamp is 0 the position data is invalid. If there is a timestamp > 0, the transmitted position data always refers to a valid position (even if the Flag *Position Valid* is 0), but at the indicated time. So the position could be quite outdated. This behaviour ensures that valid position information can be transmitted to the backend, even if the Tracker never has GPS-coverage and a LoRaWAN-connection at the same time.



Advice for use with TTN-Mapper

If you are using the device with TTN-Mapper, you must make sure that those outdated positions are not sent to TTN-Mapper! See [TTN-Mapper](#) for details.

The Position is encoded as signed *Latitude* and *Longitude* with five decimal digits of precision, put into two `int32` values. Divided by 100000 you get the degrees. Positive values stand for North/East, negative values for South/West.

The *Altitude* is encoded as cm in an `int24`.

The [Example Data Message](#) and the [Reference Parser](#) for further documentation.

Position Quality

SatCnt and *HDOP* are indicators for how good the position in the data message is.

SatCnt is a `uint8` that gives the number of satellites that were used for calculating the coordinates (more is better). The minimal number for a fix is 4. 10 satellites and more are a good value.

HDOP is the [Horizontal Dilution of Precision](#). That is a dimensionless value that indicates how precise the position can be for the current satellites' positions. The HDOP is transmitted multiplied by 10 as a `uint8`, so you need to divide it by 10 to get the actual HDOP, and it maxes out at 25.5, which is a terrible rating. Values of 1 and below are ideal, values up to 5 are considered good.



Quality of GPS data

Please be aware that position data generated using GPS and other GNSS systems has certain physical limitations in its precision. This is mainly caused by signal distortions in the atmosphere and when signals are reflected by walls (multipath effects). Therefore even with high *SatCnt* and ideal *HDOP*, the calculated position can be far of the actual position. For an introduction into the topic, you can start at [Error_analysis_for_the_Global_Positioning_System on Wikipedia](#).

Flags

The status Flag indicates the current conditions inside the application. Only two bits are used. Bit counting starts with the least significant bit with 0.

Bit	Meaning	Values
0	Position currently valid	0 = not valid, 1 = valid
1	Current operation mode	0 = Passive Mode, 1 = Active Mode

The *Position valid* flag indicates if the device did get a fix on it's position just before sending the upload. So it indicates if the message contains a new valid position. Any position uploaded with a valid timestamp is a real measured position taken at that time. See [Position](#) for details.

Example Data Message

```

Payload on Port 2:
'00D40BC40051B427000F45DA0016A803060F005ECCCE29005ECCCE20'
-----
'00D4' - Temperature
    0x00d4 = 212 = 21.2°C
'0BC4' - Voltage
    0x0bc4 = 3012 = 3.012V
'0051B427' - Latitude
    0x0051b427 = 5354535 = 53.54535°N = N 53° 32' 43.26"
'000F45DA' - Longitude
    0x000f45da = 1000922 = 10.00922°E = E 10° 0' 33.19"
'0016A8' - Altitude
    0x0016a8 = 5800 = 58m
'03' - Flags
    0x03 = 0b11 = Mode Active, Position current and valid
'06' - SatCnt
    0x06 = 6 = 6 Satellites
'0F' - HDOP
    0x0f = 15 = 1.5 HDOP
'005ECCCE29'
    0x005eccce29 = 1590480425 = 2020-05-26T08:07:05 UTC
'005ECCCE20'
    0x005eccce20 = 1590480416 = 2020-05-26T08:06:56 UTC
```

Parser

Here is a reference message parser written in JavaScript, that can be used in [The Things Network](#) to parse the Status Message and Data Message into JSON objects. If you are using your device with TTN-Mapper, please read the advices on how to modify parser and configuration under [TTN-Mapper](#).

```

/**
 * Parser for Lobar GPS-Tracker v3 to be used in The Things Network
 *
 * When used with TTN-Mapper integration set global variable
 * TTN_MAPPER to false. See https://docs.lobaro.com for details.
 *
 * Copyright 2020 Lobar GmbH - https://www.lobaro.com
 * Free to be used under MIT License:
 *
 * Permission is hereby granted, free of charge, to any person obtaining a
 * copy of this software and associated documentation files (the "Software"),
 * to deal in the Software without restriction, including without limitation
 * the rights to use, copy, modify, merge, publish, distribute, sublicense,
 * and/or sell copies of the Software, and to permit persons to whom the
 * Software is furnished to do so, subject to the following conditions:
 * The above copyright notice and this permission notice shall be included
 * in all copies or substantial portions of the Software.
 *
 * THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS
 * OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF
 * MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN
```

```

NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM,
DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR
OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE
USE OR OTHER DEALINGS IN THE SOFTWARE.
*/

/* === CONFIG === */
// Set this to true, if you are using TTN-Mapper integration. This avoids
sending
// outdated positions that TTN-Mapper would use as new data.
var TTN_MAPPER = false;

/* Helper functions used by this parser */
function signed(val, bits) {
    if ((val & 1 << (bits-1)) > 0) { // value is negative (16bit 2's
complement)
        var mask = Math.pow(2, bits) - 1;
        val = (~val & mask) + 1; // invert all bits & add 1 => now
positive value
        val = val * -1;
    }
    return val;
}
function uint40_BE(bytes, idx) {
    bytes = bytes.slice(idx || 0);
    return bytes[0] << 32 |
        bytes[1] << 24 | bytes[2] << 16 | bytes[3] << 8 | bytes[4] << 0;
}
function uint32_BE(bytes, idx) {
    bytes = bytes.slice(idx || 0);
    return bytes[0] << 24 | bytes[1] << 16 | bytes[2] << 8 | bytes[3] << 0;
}
function uint24_BE(bytes, idx) {
    bytes = bytes.slice(idx || 0);
    return bytes[0] << 16 | bytes[1] << 8 | bytes[2] << 0;
}
function uint16_BE(bytes, idx) {
    bytes = bytes.slice(idx || 0);
    return bytes[0] << 8 | bytes[1] << 0;
}
function int40_BE(bytes, idx) {return signed(uint40_BE(bytes, idx), 40);}
function int32_BE(bytes, idx) {return signed(uint32_BE(bytes, idx), 32);}
function int24_BE(bytes, idx) {return signed(uint24_BE(bytes, idx), 24);}
function int16_BE(bytes, idx) {return signed(uint16_BE(bytes, idx), 16);}
function readVersion(bytes, i) {
    if (bytes.length < 3) {
        return null;
    }
    return "v" + bytes[i] + "." + bytes[i + 1] + "." + bytes[i + 2];
}

/**
 * Decode status/error codes from GPS-Tracker to human readable tags.
 */
function decode_status_code(code) {
    switch (code) {
        case 0:
            return "OK";
        case 101:
            return "GPS_ERROR";
        case 102:
            return "MEMS_ERROR";
        case 103:
            return "GPS_AND_MEMS_ERROR";
        default:
            return "UNKNOWN";
    }
}

/**
 * Decode reboot reason explaining last reboot of device.

```

```

*/
function decode_reboot_reason(code) {
    // STM reboot code from our HAL:
    switch (code) {
        case 1:
            return "LOW_POWER_RESET";
        case 2:
            return "WINDOW_WATCHDOG_RESET";
        case 3:
            return "INDEPENDENT_WATCHDOG_RESET";
        case 4:
            return "SOFTWARE_RESET";
        case 5:
            return "POWER_ON_RESET";
        case 6:
            return "EXTERNAL_RESET_PIN_RESET";
        case 7:
            return "OBL_RESET";
        default:
            return "UNKNOWN";
    }
}

function DecoderPort2(bytes) {
    // Data Message containing position data.
    var Temp = int16_BE(bytes, 0) / 10;
    var VBat = int16_BE(bytes, 2) / 1000;
    var Lat = int32_BE(bytes, 4) / 100000;
    var Lon = int32_BE(bytes, 8) / 100000;
    var Alt = int24_BE(bytes, 12) / 100;
    var Valid = !(bytes[15] & 0x01);
    var Active = !(bytes[15] & 0x02);
    var SatCnt = bytes[16];
    var Hdop = bytes[17] / 10;
    var Time = int40_BE(bytes, 18);

    if (TTN_MAPPER && (!Valid)) {
        // TTN-Mapper specific:
        // Position is not valid, so this is outdated data. TTN-Mapper
        // cannot handle those
        // so we drop this packet on purpose:
        return {};
    }

    return {
        "temperature": Temp || 0,
        "voltage": VBat || 0,
        "latitude": Lat || 0,
        "longitude": Lon || 0,
        "altitude": Alt || 0,
        "valid": Valid,
        "active": Active,
        "satellites": SatCnt,
        "hdop": Hdop,
        "time": Time * 1000
    };
}

function DecoderStatus(bytes) {
    var firmware = String.fromCharCode.apply(null, bytes.slice(0, 3));
    var version = readVersion(bytes.slice(3, 6));
    var status_code = bytes[6];
    var status_text = decode_status_code(status_code);
    var reboot_code = bytes[7];
    var reboot_reason = decode_reboot_reason(reboot_code);
    var final_code = bytes[8];
    var vcc = (int16_BE(bytes, 9) / 1000) || 0.0;
    var temp = (int16_BE(bytes, 11) / 10) || -0x8000;
    var app_data = bytes.slice(13);

    return {

```

```

        "firmware": firmware,
        "version": version,
        "status_code": status_code,
        "status_text": status_text,
        "reboot_code": reboot_code,
        "reboot_reason": reboot_reason,
        "final_code": final_code,
        "temperature": temp,
        "voltage": vcc,
        "app_data": app_data
    };
}

function DecoderPort1(bytes) {
    var d = DecoderStatus(bytes);
    var flags = d.app_data[0] || 0x00;
    d.valid = !(flags & 0x01);
    d.active = !(flags & 0x02);
    return d;
}

function Decoder(bytes, port) {
    switch (port) {
        case 1:
            // Port 1: Status Message
            return DecoderPort1(bytes);
        case 2:
            // Port 2: Data Message (containing position data)
            return DecoderPort2(bytes);
        default:
            return {"error": "Unsupported port", "port": port};
    }
}

```

TTN-Mapper

[TTN-Mapper](#) is a community project that tries to create a global map of LoRaWAN-Coverage of the open LoRaWAN Network [The Things Network](#). Anyone with a compatible GPS-capable LoRaWAN-device can contribute to the project by submitting their data.

The Lobar LoRaWAN GPS-Tracker can easily be used as a TTN-Mapper Node, as it uploads *Latitude*, *Longitude*, *Altitude*, and *Horizontal Dilution of Precision (HDOP)*. The device should be setup with a specific configuration, and the parser used in TTN for the device must be slightly adjusted to stop outdated position data to be used in the mapper.

Configuration

The device can be used either with OTAA or ABP. The EUIs and Keys must be set accordingly to activate the device in TTN. The remaining configuration values can mostly remain on default value. A few should be adjusted as follows:

Parameter	Value	Comment
SF	7	Spreading Factor should be set to 7 according to TTN-Mapper documentation.
ADR	false	Adaptive Data Rate should be deactivated for mobile devices.
OpMode	A	No Downlinks needed.
TimeSync	0	Not supported by TTN, time is synced from GPS signal.
RndDelay	0	Random delay would distort position while moving.
activeCron	0 0/3 * *	Suggestion that uploads position every minute while active. Adjust as needed.
activeTO	5	Switch to passive mode after 5 minutes without movement.

Parser

The payload format decoder must be slightly adjusted for the use of TTN-Mapper, because the Lobar GPS-Tracker will upload its latest known valid position when no GPS-fix can be achieved (indicating so by a flag and giving the timestamp of the localisation). TTN-Mapper would parse that as a new valid position, so the parser **must drop** those messages in order to stop wrong data points to end up in TTN-Mapper.

Change the line at the top of the parser from to activate TTN_MAPPER conformity:

```
var TTN_MAPPER = false;
```

Replace it with this line:

```
var TTN_MAPPER = true;
```


Integration

Add an integration for your TTN-Application as described under <https://www.thethingsnetwork.org/docs/applications/ttnmapper/>. The Port filter must be set to 2.

You can use the TTN Mapper integration side by side with other integrations that connect to your backend /platform, so that you get the data from the GPS-Tracker while also sending them to TTN-Mapper.

Technical characteristics

Product	
Type name	GPS-LoRaWAN 3
Description	LoRaWAN GPS Tracker HW3
RF transceiver	
Chipset	Semtech SX1272
Frequency Range	863 to 870 MHz
TX Power	14 dBm
Typically RF range	2km
Ideal RF range	10km (free line of sight)
LoRa communication	
LoRaWAN Protocol	LoRaWAN 1.0.1, 1.0.3, 1.1.0, Class A/C, EU868
Activation method	Over-the-air activation (OTAA) Activation by personalization (ABP)
Encryption	AES128
Power	
Power supply	2xAA sized battery, 1.5 V, LR6/FR6
Supply voltage	UNom = 3.0V, UMin = 2.2V, UMax = 3.7V
Capacity	30000 LoRaWAN messages @SF11
Current consumption @3V	
Normal	3 mA
Wireless M-BUS RX	14 mA
LoRa RX	14 mA

LoRa TX	80 mA
Sleep with GPS standby and MEMS running	20 μ A
Mechanical dimensions	
Size	114.3 mm x 59.3 mm x 26.8 mm
Housing Material	ABS plastic
Environmental Requirements	
Operating temperature range	-20°C to +55°C
Max. Installation height	2m
Conformity	
	

Disposal

For information on disposal of the *LoRaWAN GPS-Tracker V3*, please refer to our page on [Disposal of Lobaro Devices](#).

PDF Documentation

- [Product Dimensions \(pdf\)](#)
- [CE Declaration of Conformity](#)