Devices

A device represents a single physical IoT device that might consist of multiple Sensors and Actors.

Each device has a Device Type that defines the type of the device, e.g. how data is parsed, displayed and forwarded via integrations.

 Overview Device Pro Alerts Location Device Data Uplinks & "Parser re Simulate U Downlinks Config (optional) Settings Organisatic Si Bu Device Tag 	perties turned nil" plinks n ngle Device ulk Operation s							
IoT Platform	Devices	Data	Integrations	Device Types	Organisation	Configuration	Tools	~
Devices > MFW1.3.2 - Vodafone MFW1.3.2 - Vodafone wMBus Gateway ·								
Overview Device D	ata Uplir	nks Do	ownlinks Cor	nfig Settings	Security			

When opening the device page there are multiple sub pages:

- Overview
- Device Data
- Uplinks
- Downlinks
- Config
- Settings
- Security

Overview

Device Properties

Device Properties are bound to the device and can be manipulated (read / write) by the parser and via API's.

We are planning support to Edit the properties via the User Interface as well, deletion is already possible.

See "Edit Properties" button below the property list:



Alerts

The feature is currently not supported.

Location

The device can have a physical location. The location can be set via the Web UI, APIs and by the parser.

Device Data

Device data lists all data records returned from the Parser.

The table is configured via the "Data Table Config" in the "Device Type".

Uplinks & "Parser returned nil"

Uplinks are raw sent messages from a device that were received and tried to be processed by the parser to create parsed records ("Device Data"). Not all uplinks return a good data result, then the parser result is "Parser returned nil". This is **not** a general error, but a hint that no device data could be extracted from the uplink. Often this happens with status uplinks that do not contain user data but can be processed by the parser for meta information, e.g. battery voltage, that are shown under "Device Properties".

Simulate Uplinks

For test purposes, it may be useful to simulate uplinks through the platform and let the parser process them again. For this purpose, the "data" part of a past upload can be used, as shown in the highlighted part below.

Overview	Device Data	Uplinks	Downlinks	Config	Settings	Security	
\leftarrow Prev	Page 1 Item	ns 1 100	Next \rightarrow				
RE	CEIVED	TYP	E DATA	SOURCE	PARSE	R RESULT	
✓ 14.0	04.2023 08:53:	35	http				
 ✓ 14.0 	04.2023 02:40:	41 statu	is coap		Parser r	returned nil	
× 13.0	04.2023 14:05:1	15 statu	is coap		Parser i	returned nil	
∧ 13.0	04.2023 14:05:1	14	coap				
"parm" "dati "dati "d' ", ", ", ", ", ", ", ", ", ", ", ", ",	<pre>seError": "", asource": nul sourceString ": { "mode": "T", "rssi": -56, "telegram": " "timestamp": ": "e8eblbff; ": 65</pre>	, 11, "'' COBD" "LkSwCYcyA 168138736 £e4d235e",	BhUCHrBAAAg 7	Ly8DboUI;	AA8QAAG1Yn	icungc6Dj¥uAAAAAAAAA	SFCAA=",

The copied data can then be pasted in under the "Settings" Tab and send to the platform again for processing with a click on "Send Data". This data then appears again under "Uplinks" with "http" as datasource. Downstream processing, including any integrations, is then just as if the data had been sent from a physical device.

Simulate Uplink



Downlinks

A list of queued and sent downlinks.

Config (optional)

Requires Trait:

Remote Config Update

The config tab is only displayed when the Device Type has the Trait "Remote Config Update"

Allows to see and edit the device configuration.

Config properties must be updated by the parser, else the page is empty.

Updating configuration only works for NB-IoT devices yet (10/2022).

Settings

Edit devices Settings:

- Name User friendly display name
- · Address used to identify the device when receiving Incoming data
- Serial Serial number, provided in device import
- Device Tags see below
- Description User friendly description of the device
- Device Type
- App ¹/₁ Deprecated
- Datasource allows to assign additional Pull or MQTT based datasources
- Parser Parser to handle uplinks and generate device data

Organisation

Each device belongs to a zero or one Organisation. There are multiple ways to move the device to another organisation.

Role: admin, org-admin

org-admin can move the device between different Sub Organisations in his Organisation tree.

Single Device

Go to: Configuration Hardware Find and open the Device Page

Change the Organisation



Press Save



Bulk Operation

Go to: Configuration Hardware

Select multiple devices

Click "Bulk Operations"

💉 Bulk Operations	
-------------------	--

Change the Organisation and press "Bulk Update"

 Change Organisation: Organisation 					
Change Device Type: Device Type					
💾 Bulk Update	× Cancel				

Device Tags

Tags on device level are meant to group devices inside an organisation. Use cases can can be external ID's, Installation location, data export targets, etc. Some future plans are to filter by tag in integrations, display tags in the device table and use them for search, grouping, etc.

Currently the most important difference to device properties (where you can also story lists) is, that the parser has no write access to tags. Also a device with too many tags might get less handy, where device properties can be added as needed.