# LoRaWAN

# Introduction to LoRaWAN

LoRaWAN stands for Long Range Wide Area Network and is a low power wireless network protocol. It uses the wireless transmission technology *LoRa*, owned by Semtech Corporation. Although LoRa is a proprietary and patented, LoRaWAN can is openly specified by the LoRa Alliance and can be used freely if you have the necessary hardware. It is using publicly available frequencies to transmit its data.

Transmissions using LoRaWAN can travel distances of several kilometers and are very good at penetrating obstacles like walls. Communication using LoRaWAN does also require very little power, so you can achieve long lifetimes for battery powered devices. The trade off is a very limited data rate which makes it unusable for some use cases. For many IoT applications this is not really a limitation.

LoRaWAN based LPWANs (Low Power wide area networks) allow connections to the Internet from small battery powered devices with wireless ranges of up to 5 kilometers between the transmitter and receiving gateway antenna - without the usual cellular network costs in classical M2M or smart metering solutions. Also - unlike with cellular networks - it's possible to setup own gateways if needed.

To operate LoRaWAN Sensors you need a LoRaWAN Network Server. A free to use, open source network server is The Things Network. They provide a very good documentation about the overall architecture and features of LoRaWAN:

LoRaWAN Documentation (by TTN)

# LoRa

LoRa is the modulation used in LoRaWAN. It's patented by Semtech.

To calculate LoRa specific parameters like transmit time you can use the SX1272 LoRa Calculator from Semtech.

### Gateways

All LoRaWAN devices connect to a LoRaWAN Network via Gateways. Those are stationary devices that collect LoRaWAN messages from the air and forward them over the Internet to the LoRaWAN Network. You need at least one Gateway to operate a LoRaWAN device; you can either set it up yourself or use infrastructure provided by others. Lobaro does not manufacture Gateways, but we can advice you and help you acquire them, if you need support.

### **Network Server**

The Network Server is the part of a LoRaWAN Network that coordinates Sensors and Gateways and lets you access the data your devices are uploading. There exists a free to use Network Server named The Things Network (TTN), which is a good place to start using LoRaWAN. There are even a lot of publicly available Gateways in the world that connect to TTN which you can use with your devices. Depending on your location their might also be commercial LoRaWAN Networks available that you can use.

Lobaro does not develop its own Network Server, but we can connect LoRaWAN devices to our backend via a Network Server we are operating, via TTN, or via any other LoRaWAN provider that supplies an API that we can connect to.

# **Uplinks and Downlinks**

Messages sent by a LoRaWAN device to the Network are called *Uplink*, messages sent from the Network to the device are called *Downlinks*. For normal LoRaWAN use cases Uplinks are sent much more often then Downlinks. A Gateways is limited in the number of Downlinks it may send over time, so Network Providers tend to charge fees for Downlinks.

The situation on which Downlinks can be sent to a device are very limited. LoRaWAN has three different Operation Modes: Class A, Class B, and Class C. Devices running in the most common Operation Mode, Class A, can only receive a Downlink Message directly after they send an Uplink. This makes it possible for LoRaWAN devices to operate on very little power, because they spend most of their time in a sleeping state. As a consequence every Downlink you send to your devices will be buffered until it sends an Uplink and only then the Downlink will be transmitted. Depending on the device and it's configuration, this can take hours or days.

Operation Mode Class C gives a solution to this problem. A device operating in Class C is listening for Downlinks whenever possible, thus it is (almost) always reachable by the network. This permanent receiving prevents the device from going into a sleep mode, so devices running in Class C will consume much more power. It is not advisable to run battery powered devices in Class C.

All LoRaWAN devices support Class A. Some Lobaro devices can be changed to run in Class C by configuration. Class B is not supported by Lobaro devices at the moment.

- Introduction to LoRaWAN
  - ° LoRa
  - ° Gateways
  - Network Server
  - Uplinks and
  - Downlinks
  - Further Information
- Lobaro LoRaWAN stack

   LoRaWAN versions
  - LoRaWAN
  - Configuration
  - Using ABP
- Duty Cycle
- Spreading Factor
- Timestamp
- Parser

### **Further Information**

- TTN provide a good LoRaWAN Documentation
- The Official LoRaWAN Specification is developed and provided by the LoRa Alliance.

# Lobaro LoRaWAN stack

Lobaro's LoRaWAN devices use a LoRaWAN stack we develop ourselves. It supports a wide spectrum of features:

- LoRaWAN version 1.1 and 1.0 supported
- Over The Air Activation (OTAA) and Activation By Personalisation (ABP)
- Adaptive Data Rate (ADR)
- Device integrated DevEUI (alternatively DevEUI can be freely configured)
- AES encryption
- LoRaWAN operation modes Class A and Class C
- Time synchronisation over LoRaWAN
- Remote configuration over LoRaWAN
- Remote device rebooting
- Automated reconnection on network loss
- · Random delays to avoid collisions with other devices

Some devices implement only a subset of those features.

# LoRaWAN versions

The most recent version of LoRaWAN is 1.1. Some Network Servers support only version 1.0. The configuration for the two versions is slightly different: Version 1.1 has two Keys: The *Network Key* NwkKey and the *Application Key* AppKey. Version 1.0 only uses the Application Key.

Lobaro's LoRaWAN devices support both versions. If both keys, NwkKey and AppKey are set, the device uses version 1.1. If NwkKey is set to all zeros, the device uses version 1.0 instead. If both keys are set to the same value, the device tries to use version 1.1 but falls back to 1.0 if the Network Server does not support 1.1.

The initial configuration for Lobaro's LoRaWAN devices has both keys set to the same value, so that they can be used with both LoRaWAN versions out of the box. Each device has an individual key, but the value is known to Lobaro. For security reasons the keys should be changed to a random value generated from a strong random source.

# **LoRaWAN** Configuration

The configuration of the LoRaWAN parameters is basically the same for all LoRaWAN devices (some of our products might differ in some details, especially devices using older firmware that do not yet support LoRaWAN 1.1).

Several values are a number of bytes, that need to be entered as hexstrings (without 0x-prefix). So e.g. the DevEUI is a value of 8 bytes encoded in hex will be 16 hexdigits long. A sample value would be 0123 456789abcdef.

Name	Description	Туре	Values
OTAA	Activation: OTAA or ABP	bool	true= use OTAA, false= use ABP
DevEUI	DevEUI used to identify the Device	byte[8]	<b>e.g.</b> 0123456789abcdef
JoinEUI	Used for OTAA (called AppEUI in v1.0)	byte[8]	<b>e.g.</b> 0123456789abcdef
АррКеу	Key used for OTAA (v1.0 and v1.1)	byte[16]	
NwkKey	Key used for OTAA (v1.1 only)	byte[16]	
SF	Initial / maximum Spreading Factor	int	7 - 12
ADR	Use Adaptive Data Rate	bool	<pre>true= use ADR, false= don't</pre>
OpMode	Operation Mode	string	A= Class A, C= Class C
TimeSync	Days after which to sync time	int	days, 0=don't sync time
RndDelay	Random delay before sending	int	max seconds
RemoteConf	Support Remote Configuration	bool	true=allow (default), false=deactivate
LostReboot	Days without downlink before reboot	int	days, 0=don't reboot

#### ΟΤΑΑ

LoRaWAN device needs to be activated to communicate with a network. The activation generates a session that is used by the device and most importantly sets the encryption keys used for communication during the session's lifetime. There are two ways to handle the activation. One is Activation Over The Air (OTAA), which uses shared secrets to create new session keys when the device connects to the Network (join). The other is Activation By Personalisation (ABP), where the session keys have to be communicated between the device and the Network Server previously on a channel outside of the LoRaWAN spec. We recommend to use OTAA whenever possible, as it creates new keys on each join procedure, making it harder to break the encryption. If you need to use ABP despite this, please referre to using ABP for an explanation of how to get the keys needed.

#### DevEUI

The DevEUI is an 8 byte value that identifies the device globally. Lobaro LoRaWAN devices contain a unique DevEUI officially purchased from a distributor. If you need to use a different DevEUI for some reason you can change it to any value you like. The original DevEUI will remain in the device and can be restored by resetting the configuration to default. It is also displayed as a log message when booting the device. The DevEUI identifies a device in the Network Server when you are using OTAA.

#### JoinEUI

The JoinEui is an 8 byte value that is needed during OTAA join. It often provided as a random value by the Network server. In LoRaWAN 1.0 this was called AppEUI and had a slightly different function. The AppEui for LoRaWAN 1.0 is often provided by the Network Server. If you are using 1.0 set the AppEui here.

#### AppKey, NwkKey

The Application Key and the Network Key are used as shared secrets during OTAA to generate the session keys. They need to be synchronised between the device and the Network Server. LoRaWAN 1.0 only uses the AppKey and not the NwkKey. Setting the NwkKey

#### SF

The Spreading Factor is a LoRa parameter that defines how much time is used to transmit a single byte. A higher Spreading Factor results in a better reception of the transmission, but it has a severe impact on the amount of data a device can send and on battery consumption. See Spreading Factor for more details. This Parameter sets the Spreading Factor the device starts with after Activation. If the device uses ADR, the Spreading Factor can change over time, but it will never be higher than the value configured here.

#### ADR

Adaptive Data Rate (ADR) allows the Network Server to adjust the Spreading Factor and TxPower of this device. This feature helps the Network to organise itself when multiple devices and multiple gateways are in one area. It also helps the device to reduce power consumption, as the Network Server can reduce the power used by the device for transmission. ADR works best with devices that are stationary or move only rarely. A highly mobile device will often experience sudden reductions in connectivity. This can lead to packet loss when the Data Rate is configured to be as low as possible.

#### OpMode

LoRaWAN devices can operate in different modes. The most common Operation Mode is Class A. In this Mode the device only listens for downlink messages for a short period after it sent an uplink message to the network. Those devices can only be reached when they contact the network. This is the preferred Operation Mode for battery powered device, because it allows the device to spend most of its time in a deep sleep state that consumes only minimal power. The other Operation Mode supported by Lobaro is Class C. Devices in this modus listen for downlink messages whenever possible. This allows the Network to contact the device at almost any time without waiting for an incoming uplink. This Operation Mode consumes much more power and is not recommended for battery powered devices!

#### TimeSync

When the device is connected to power it does not know what the time and sets its internal clock to 2010-01-01T00:00:00. For many use cases it is necessary that the device's clock is set to the correct time (for example if the device needs to activate at a specific point in time). LoRaWAN supports synchronizing time over the air. When TimeSync is set to a number > 0 the device synchronizes time on activation and then again and again after that number of days have passed. A regular synchronization is useful, because the devices clock has a limited precision and might drift several seconds per month.Not all Network Servers support time synchronization. Some Network Servers will silently drop any message that requests a time synchronization. This can result in packet loss. If your Network Server has this limitation, make sure you deactivate this feature.When using multiple time synchronized devices around the same Gateway you should use RndDelay to avoid collisions.

#### RndDelay

When multiple devices try to transmit at the same time they interfere with each other leading to packet loss. Because the devices wake up on a specific time those collisions can repeat for each operation cycle. An effective feature to avoid repeating collisions is adding a random delay before transmission. RndDelay specifies a maximal number of seconds that is randomly waited before the device starts uploading its data. The delay is performed after taking measurements but before uploading, so that the measurements take place at a well defined time.

#### RemoteConf

Our devices support changing the configuration over the air via LoRaWAN downlinks. This can be a very convenient feature for devices that are difficult to get physical access to. For security reasons this feature can be deactivated using this configuration parameter. See Remote Configuration for more information.

#### LostReboot

This feature allows the device to detect a disconnection from the Network and to reboot in that case. If the device does not receive any downlinks for the specified number of days it reboots itself in order to rejoin the network. This only makes sense for devices using OTAA, as ABP devices do not start a new session on boot. In combination with TimeSync you can ensure downlinks on a regular basis to test connection. This feature makes it possible to move an OTAA using device from one Network to another without the need to restart it manually through physical access.

### Using ABP

We recommend using OTAA for the activation of your devices, as it is more flexible and more secure. Still there are cases were you need to use ABP. Our devices support ABP (Activation By Personalisation). To use it, you need to set the configuration parameter OTAA to false. The required parameters for ABP will be created by the device. You can see them in the log after boot. The amount of keys used for ABP differ between LoRaWAN Versions 1.0 and 1.1, so, depending on which version you set the device to use, the output will differ:

Example for LoRaWAN v1.0:

LoRa | LoRaWAN config LoRa | using LoRaWAN v1.0, ABP LoRa | configuration derived from DevAddr, AppKey LoRa | DevAddr: 0014331e (last 4 bytes of DevEUI) LoRa | NetSKey: 02ce3eb181b2eea2cb02e8a6d237b07b LoRa | AppSKey: e8566e3fb69d65067bf51846eff1271a

#### Example for LoRaWAN v1.1:

LoRa	LoRaWAN config LoRa using LoRaWAN v1.1, ABP
LoRa	configuration derived from DevAddr, NwkKey, AppKey
LoRa	DevAddr: 0014331e (last 4 bytes of DevEUI)
LoRa	change AppKey and NwkKey to generate different Keys
LoRa	NwkSEncKey: 12bf6aac2faba7b74160d1223eb44fd1
LoRa	SNwkSIntKey: 0f4edac1f38b2a52389c4dd42fa65330
LoRa	FNwkSIntKey: db264cf386c242caba4f842cb014947b
LoRa	AppSKey: 3256663fb79d65067bf51646eff0271a

You can copy the device address and session keys from the log and put them into your Network Server's configuration. The device address is generated using the last 4 bytes of the DevEUI, so if you want to change the Address you will have to change the DevEUI in the configuration. The Session Keys are derived from the OTAA keys in the configuration, so if you want to generate different session keys, you should set the AppKey (for v1.0) or the AppKey and NwkKey (for v1.1) to a randomly generated value.

# Duty Cycle

Because LoRaWAN uses public frequencies, there are some regulations LoRaWAN device must comply to. Radio transmissions are subject to local legislation; the information in this chapter are referring to EU regulations. Other areas have similar regulations but they will differ in detail.

Devices that use public frequencies must respect a *duty cycle* for transmissions: a device must not transmit more than 1% of the time on a certain band. So after 1 second of transmission the device must not use that band for at least 99 seconds. So if a device has a lot of data to upload, it will be forced into waiting after the first few uploads. Our devices will go to a very power effective sleep mode when they are forced to wait. When using LoRa modulation, the Spreading Factor used has a severe impact how much data can be uploaded in a fixed amount of time. See next chapter Spreading Factor for more details.

# Spreading Factor

The Spreading Factor (SF) is a parameter of LoRa ranging from 7 to 12, that defines how much transmission time is used to transmit a single byte. Using a higher spreading factor results in a higher possibility to get a message transmitted successfully. The trade off is, that it takes a longer time to transmit, which leads to a higher power consumption, more collisions between devices, and much smaller data throughput for the device because of the duty cycle. Increasing the spreading factor by one doubles the amount of time it takes to transmit data and therefore halves the amount of data that can be transmitted. A higher spreading factor also leads to a stricter size limitation for messages. On SF 7 a single message can carry a payload of up to 242 bytes, on SF 12 only 51 bytes are allowed. It is therefore advisable to use the lowest possible spreading factor for your devises. Tuning this by hand is a difficult task, but there is a mechanism called *Adaptive Data Rate* (ADR) that does this for you.

Enabling ADR in your device allows the Network Server to change the Spreading Factor of your device according to the reception quality. The SF will never be set higher than the starting value you configure in your device. Most of our devices are configured to use ADR and to start at a SF of 12. This gives the Network Server full flexibility in organizing all attached devices and should result in the optimal configuration. It gives the network the ability to adapt to changes, like an increase of the number of deployed devices, or to the installation of additional gateways (or a gateway stopping to work).

Spreading Factor	Max Payload
12	51
11	51
10	51
9	115
8	242
7	242

# Timestamp

Many of our devices include timestamps somewhere in their payloads. The encoding of timestamps in our payload is the same in all our LoRaWAN devices except some of our oldest. There are some details you should be aware of.

- 1. Format: Points in time are represented as UNIX-timestamps within our products. That is a integer value indicating the number of seconds that have passed since 0:00h on January 1 1970 in UTC.
- 2. Encoding: We encode the UNIX-timestamp in a signed 40 bit big endian integer (int40, 5 bytes long). The 40 bit integer is unconventional but used with good reasoning. UNIX-timestamps have traditionally been stored as signed 32 bit integers (int32). This poses the problem that points in time later than January 2038 cannot be expressed. A simple solution to this is switching to store timestamps in singed 64 bit integers. This is a suitable solution for modern computers and our devices do that internally for calculations. The problem is that 64 bit integers take 8 bytes of space, and with LoRaWAN every byte is precious. 3 of those 8 bytes will be zeros for thousands of years to come, so we chose to increase the size of our timestamps by only a single byte to 40 bit. This lets us store timestamps up unto the year 19391, which we dare say is enough.

Storing numerical values with a number of bits that is not a power of 2 might be unusual, but there is nothing wrong with it. If you have problems decoding 40 bit values you can find an example implementation in JavaScript below in our example TTN parser.

3. Device's internal clock: The timestamp uploaded by the devices is always referring to the device's internal clock. That clock is not always in sync with actual time. In fact when you power up the device it has no way to know what time it is. It sets the internal clock to 2010-01-01T00:00:00. For many applications this is not a problem! If you set the device's cron to execute at 0h, 6h, 12h, and 18h it will activate every 6 hours at the same times every day. But when exactly the device is activated depends on the the time it was first powered on. If you require your device to run in sync with actual time you can set its clock using the configuration adapter and the Lobaro Tool. LoRaWAN 1.1 also introduced time synchronization over the air which is supported by some of our devices. You will need to use a LoRaWAN Network Server that also supports this feature.

# Parser

LoRaWAN Application Servers need to decode sensor payloads. This is done with custom parser code. We provide TTN compatible JavaScript parsers as reference implementation for all our devices.

Some common help functions for this parsers can be found in the following example:

```
// Convert a hex string to a byte array
function hexToBytes(hex) {
   for (var bytes = [], c = 0; c < hex.length; c += 2)
       bytes.push(parseInt(hex.substr(c, 2), 16));
   return bytes;
}
// Convert a byte array to a hex string
function bytesToHex(bytes) {
    for (var hex = [], i = 0; i < bytes.length; i++) {</pre>
        var current = bytes[i] < 0 ? bytes[i] + 256 : bytes[i];</pre>
        hex.push((current >>> 4).toString(16));
       hex.push((current & 0xF).toString(16));
    }
    return hex.join("");
}
// Note that MAX_SAFE_INTEGER is 9007199254740991
function toNumber_BE(bytes, len, signed) {
    var res = 0;
    var isNeg = false;
    if (len == 0) {
       len = bytes.length;
    }
    if (signed) {
       isNeg = (bytes[0] & 0x80) != 0;
    }
    for (var i = 0; i < len ; i++) {
        if (i == 0 && isNeg) {
            // Treat most-significant bit as -2^i instead of 2^i
            res += bytes[i] & 0x7F;
            res -= 0x80;
        } else {
           res *= 256;
           res += bytes[i];
        }
    }
    return res;
}
// Note that MAX_SAFE_INTEGER is 9007199254740991
function toNumber_LE(bytes, len, signed) {
   return toNumber_BE(bytes.reverse(), len, signed);
}
function int16_BE(bytes, idx) {
   bytes = bytes.slice(idx || 0);
    return toNumber_BE(bytes, 2, true);
}
function int24_BE(bytes, idx) {
   bytes = bytes.slice(idx || 0);
    return toNumber_BE(bytes, 3, true);
}
function int32_BE(bytes, idx) {
    bytes = bytes.slice(idx || 0);
    return toNumber_BE(bytes, 4, true);
}
function int40_BE(bytes, idx) {
   bytes = bytes.slice(idx || 0);
    return toNumber_BE(bytes, 5, true);
}
function int64_BE(bytes, idx) {
    bytes = bytes.slice(idx || 0);
    return toNumber_BE(bytes, 8, true);
```

```
function int16_LE(bytes, idx) {
   bytes = bytes.slice(idx || 0);
    return toNumber_LE(bytes, 2, true);
}
function int24_LE(bytes, idx) {
    bytes = bytes.slice(idx || 0);
   return toNumber_LE(bytes, 3, true);
}
function int32_LE(bytes, idx) {
   bytes = bytes.slice(idx || 0);
   return toNumber_LE(bytes, 4, true);
}
function int64_LE(bytes, idx) {
    bytes = bytes.slice(idx || 0);
    return toNumber_LE(bytes, 8, true);
}
// float32([62, 132, 168, 155]) = 0.305068
function float32(bytes, idx) {
   bytes = bytes.slice(idx || 0);
    bytes = int32_BE(bytes, 0)
    var sign = (bytes >> 31) == 0 ? 1 : -1; // Comparison with 0x80000000
fails on 32 bit systems!
   var exponent = ((bytes >> 23) & 0xFF) - 127;
    var significand = (bytes & \sim(-1 << 23));
    if (exponent == 128) {
        // Some systems might have issues with NaN and POSITIVE_INFINITY,
e.g. JSON parsing in GoLang
       return sign * ((significand) ? Number.NaN : Number.
POSITIVE_INFINITY);
   }
    if (exponent == -127) {
        if (significand == 0) return sign * 0.0;
        exponent = -126;
       significand /= (1 << 22);
    } else {
      significand = (significand | (1 << 23)) / (1 << 23);
    }
    return sign * significand * Math.pow(2, exponent);
}
function bit(byte, idx) {
  return (byte & (0x01 << idx)) != 0;
} function readVersion(bytes, idx) {
   bytes = bytes.slice(idx || 0);
    return "v" + bytes[0] + "." + bytes[1] + "." + bytes[2];
}
// EXAMPLE PARSER:
// 0001000566566D3800000000600E600EA0C02400040E740C7
// 00 01 00 05 66 56 6D 38 00 00 00 00 06 00 E6 00 EA 0C 02 400040E740C7
/*
Alarm
_____
reason: Button 2 (5)
sensorTime: 946689638
vBat: 3306
temperature: 230
mems: <64,-6336,-14528>
button1State: 0
button2State: 1
```

}

```
alarmAgeSec: 6
*/
// Decoder function for TTN
function Decoder(bytes, port) {
    // Decode an uplink message from a buffer
    // (array) of bytes to an object of fields.
   var decoded = {
        "version": readVersion(bytes, 0),
        "reason": bytes[3],
        "sensorTime": int64_LE(bytes, 4),
        "alarmAgeSec": int16_LE(bytes, 12),
        "temperature": int16_LE(bytes, 14) / 10,
        "vBat": int16_LE(bytes, 16) / 1000,
        "button1State": bit(bytes[18], 0),
        "button2State": bit(bytes[18], 1),
        "memsX": int16_LE(bytes, 19),
        "memsY": int16_LE(bytes, 21),
        "memsZ": int16_LE(bytes, 23),
    };
    // if (port === 1) decoded.led = bytes[0];
   return decoded;
}
// Wrapper for Lobaro Platform
function Parse(input) {
    // Decode an incoming message to an object of fields.
    var b = bytes(atob(input.data));
   var decoded = Decoder(b, input.fPort);
   return decoded;
}
// Wrapper for Loraserver / ChirpStack
function Decode(fPort, bytes) {
   return Decoder(bytes, fPort);
}
// Wrapper for Digimondo niota.io
// Uncomment only when used in niota!
/*
module.exports = function (payload, meta) {
  const port = meta.lora.fport;
   const buf = Buffer.from(payload, 'hex');
   return Decoder(buf, port);
}*/
```